GIPRO X-TYPE GEAR INDICATOR
Supplementary Manual

Remove the seat.

Remove the frame covers under the fuel tank at both side.

Lift up or remove the fuel tank.

Route the GPX cable through the top opening of the dust boot.

Plug the GPX connectors in-line with the speed sensor connectors.

(Transparent, 3-pole connectors in dust boot at the left side)

Connect the GPX Black/Green wire to the Yellow/Green wire of the ECU/ECM connector.

(Black connector under the seat)

GIPRO X-TYPE GEAR INDICATOR
Supplementary Manual

Typical position for the gear indicator.

Secure the unit properly.