GIPRO X-TYPE GEAR INDICATOR
Supplementary Manual

Remove the seats.

Remove the Black frame covers at both side from under the fuel tank.

Lift up or remove the fuel tank.

Route the GPX cable through the top opening of the dust boot.

Plug the GPX connectors in-line with the speed sensor connectors.

(Black, 3-pole connectors in the dust boot at the left side)

GIPRO X-TYPE GEAR INDICATOR
Supplementary Manual

Connect the GPX Black/Green wire to the Yellow wire of the Crankshaft Position Sensor connector.

(Blue, 2-pole connector in the dust boot at the left side)

Typical position for the gear indicator.

Secure the unit properly.