

# GIPRO X-TYPE GEAR INDICATOR

## Supplementary Manual

### Suzuki GSF1200 Bandit 2001-2006 (GPXT + GPX-S01)

Remove the main seat.

Remove the front and middle black frame covers at the left side.



Remove the knob of fuel tap.

Lift up or remove the fuel tank.



Plug the GPX connectors in-line with the speed sensor connectors.

*(Black, 3-pole connectors at the left side near the main relay)*



# GIPRO X-TYPE GEAR INDICATOR

## Supplementary Manual



### Suzuki GSF1200 Bandit 2001-2006 (GPXT + GPX-S01)

Connect the GPX Black/Green wire to the Black/Blue wire of the ECU/ECM unit.

*(Black, 8-pole connector at the left side below the rear fairing)*



Typical position for the gear indicator.

Secure the unit properly.

